

CUSCO ANTI-SWAY BAR

Car Model

Attachment Position	OUTER DIAMETER	PARTS No.	Ratio with Standard	Remarks
SUBARU				
IMPREZA GC8(Turbo Charger)				
FRONT	18	660 311 A18		Including Sutabilizer bushes, (Note 1)
FRONT	21	660 311 A21	133%	Including Sutabilizer bushes, (Note 1)
FRONT	22	660 311 A22	120%	Including Sutabilizer bushes, (Note 1)
REAR	19	660 311 BJ19	146%/173%/206%	Three-step adjustment, Including Sutabilizer bushes, (Note 1)
REAR	21	660 311 BJ21	206%/240%/286%	Three-step adjustment, Including Sutabilizer bushes, (Note 1)
IMPREZA GDB MODEL:A,B (Turbo Charger,Include Spec C)				
FRONT	21	667 311 A21	136%(113%)	Including Sutabilizer bushes
FRONT	22	667 311 A22	175%(138%)	Including Sutabilizer bushes
REAR	22	666 311 BJ22	135%/148%/185%	Three-step adjustment, Including Sutabilizer bushes
IMPREZA GDB MODEL:C,D (Turbo Charger,Include Spec C)				
FRONT	21	667 311 A21	113%	Including Sutabilizer bushes
FRONT	22	667 311 A22	138%	Including Sutabilizer bushes
REAR	22	669 311 BJ22	135%158%173%	Three-step adjustment, Including Sutabilizer bushes
IMPREZA WAGON GGA MODEL:A,B(Turbo Charger)				
FRONT	21	667 311 A21	113%	Including Sutabilizer bushes
FRONT	22	667 311 A22	138%	Including Sutabilizer bushes
REAR	22	666 311 BJ22		Three-step adjustment, Including Sutabilizer bushes
FORESTER SF5(Turbo Charger)				
FRONT	21	660 311 A21		Including Sutabilizer bushes, (Note 1)
FRONT	22	660 311 A22		Including Sutabilizer bushes, (Note 1)
REAR	16	675 311 BJ16	235%298%346%	Three-step adjustment, Including Sutabilizer bushes
FORESTER SG5(Turbo Charger)				
FRONT	23	676 311 A23	136%	Including Sutabilizer bushes
REAR	19	676 311 BJ19	141%180%	Two-step adjustment, Including Sutabilizer bushes
LEGACY B4 BE5(Turbo Charger)				
FRONT	22	660 311 A22	120%	Including Sutabilizer bushes, (Note 1)
REAR	18	680 311 B18		For standard Sutabilizer bushes
LEGACY WAGON BF5(4WD,Turbo Charger) 92.6 ~ 93.9				
FRONT	21	660 311 A21	133%	Including Sutabilizer bushes, (Note 1)
REAR	19	658 311 BJ19	146%/173%/206%	Three-step adjustment, Including Sutabilizer bushes, (Note 1)
LEGACY WAGON BG5(Turbo Charger)				
FRONT	22	660 311 A22	136%	Including Sutabilizer bushes, (Note 1)
FRONT	21	660 311 A21		Including Sutabilizer bushes, (Note 1)
REAR	19	658 311 BJ19	146%/173%/206%	Three-step adjustment, Including Sutabilizer bushes, (Note 1)
REAR	21	658 311 BJ21	206%/240%/286%	Three-step adjustment, Including Sutabilizer bushes, (Note 1)
LEGACY WAGON BH5(Turbo Charger)				
FRONT	22	660 311 A22	136%	Including Sutabilizer bushes, (Note 1)
FRONT	21	660 311 A21		Including Sutabilizer bushes, (Note 1)
REAR	18	680 311 B18	156%	For standard Sutabilizer bushes

(Note 1): Some vehicles use stanndard sutabilizer bushes