

## CUSCO ANTI-SWAY BAR

Car Model

Attachment Position	OUTER DIAMETER	PARTS No.	Ratio with Standard	Remarks
---------------------	----------------	-----------	---------------------	---------

## TOYOTA

## Starlet Turbo Charger EP82

FRONT	16	104 311 A		For Gravel , For sutanderd inner diameter bush
FRONT	18	104 311 B		For Gravel , For sutanderd inner diameter bush

## Starlet Turbo Charger EP82

FRONT	16	104 311 AN		For Gravel , For sutanderd inner diameter bush
FRONT	18	104 311 BN		For Gravel , For sutanderd inner diameter bush

## MR-S ZZW30

FRONT	22	157 311 A22	150%	Including Sutabilizer bushes
REAR	18	157 311 BJ18	179%/260%	Two-step adjustment, Including Sutabilizer bushes

## MARK ,CHASER JZX90,100

FRONT	30	175 311 A30		Including Sutabilizer bushes and Brackets
REAR	21	175 311 B21		Including Sutabilizer bushes

## MARK JZX110(2500cc turbo charger)

FRONT	30	175 311 A30	158%	Including Sutabilizer bushes and Brackets
REAR	16	195 311 B	125%	For standard Sutabilizer bushes

## ALTEZZA SXE10

FRONT	30	175 311 A30	140%	Including Sutabilizer bushes and brackets
REAR	16	195 311 B	125%	For standard Sutabilizer bushes