

VACANZA ANTI-SWAY BAR

Car Model

Attachment Position	OUTER DIAMETER	PARTS No.	Ratio with Standard	Remarks
---------------------	----------------	-----------	---------------------	---------

HONDA

ODYSSEY RA1,2,4

FRONT 30 355 311 VA30 140% For standard Sutabilizer bushes

ODYSSEY RA6 (Include ABSOLUTE)

FRONT	30	359 311 VAJ30	120%/135%	Two-step adjustment, Including Sutabilizer bushes
REAR	28	359 311 VBJ28	151%/177%	Two-step adjustment, Including Sutabilizer bushes

ODYSSEY RA8

FRONT	30	359 311 VAJ30	120%/135%	Two-step adjustment, Including Sutabilizer bushes
REAR	28	359 311 VBJ28	129%/151%	Two-step adjustment, Including Sutabilizer bushes
ODYSSEY		RA9 (Include ABSOLUTE)		

FRONT	30	350 311 VA 130	120% /120%
-------	----	----------------	------------

FRONT 30 359 311 VA350 120% / 135% Two-step adjustment, including stabilizer bushes

FRONT 33 371 311 VA32

FRONT 32 371311 VA32 121% For standard stabilizer bushes

FRONT 22 372 311 VA 122

FRONT 22 372 311 VA222 127/167 145% Two-step adjustment, including Sutabilizer bushes

FRONT 32 371 311 VA32

FRONT 32 571 571 VASE 12170 110 Standard Cutaway Busies

REAR 23

CL 3

FRONT	30	342 311 VAJ30	137%/158%	Two-step adjustment, Including Sutabilizer bushes
REAR	20	343 311 VBJ20	134%/178%	Two-step adjustment, Including Sutabilizer bushes

ACCORD WAGON

CF6

FRONT	30	342 311 VAJ30	137%/158%	Two-step adjustment, Including Sutabilizer bushes
REAR	18	342 311 VBJ18	230%/285%	Two-step adjustment, Including Sutabilizer bushes

ACCORD WAGON

CH9

FRONT	30	342 311 VAJ30	118%/136%	Two-step adjustment, Including Sutabilizer bushes
REAR	18	342 311 VBJ18	175%/190%	Two-step adjustment, Including Sutabilizer bushes