

# VACANZA ANTI-SWAY BAR

Car Model

Attachment Position	OUTER DIAMETER	PARTS No.	Ratio with Standard	Remarks
---------------------	----------------	-----------	---------------------	---------

## SUBAU

### IMPREZA WAGON GF8 (Turbo charger)

FRONT	21	658 311 VA21	133%	Including Sutabilizer bushes. (Note 1)
-------	----	--------------	------	--

### LEGACY WAGON BF5(4WD,Turbo Charger) 92.6 ~ 93.9

FRONT	21	658 311 VA21	133%	Including Sutabilizer bushes, (Note 1)
REAR	19	658 311 VBJ19	146%/173%/206%	Three-step adjustment, Including Sutabilizer bushes, (Note1)

### LEGACY WAGON BG5(Turbo Charger)

FRONT	22	680 311 VA22	136%	Including Sutabilizer bushes, (Note 1)
FRONT	21	658 311 VA21		Including Sutabilizer bushes, (Note 1)
REAR	19	658 311 VBJ19	146%/173%/206%	Three-step adjustment, Including Sutabilizer bushes
REAR	21	658 311 VBJ21	206%/240%/286%	Three-step adjustment, Including Sutabilizer bushes

### LEGACY WAGON BH5(Turbo Charger)

FRONT	22	680 311 VA22	136%	Including Sutabilizer bushes, (Note 1)
FRONT	21	658 311 VA21		Including Sutabilizer bushes, (Note 1)
REAR	18	680 311 VB18	156%	For standard Sutabilizer bushes

### LEGACY WAGON BP5(Turbo Charger)

FRONT	22	684 311 VA23	132%	Including Sutabilizer bushes,
REAR	18	684 311 VBJ21	224%/266%	Two-step adjustment, Including Sutabilizer bushes

### FORESTER SF5(Turbo Charger)

FRONT	21	680 311 VA22		Including Sutabilizer bushes, (Note 1)
FRONT	22	658 311 VA21		Including Sutabilizer bushes, (Note 1)

### LEGACY B4 BE5(Turbo Charger)

FRONT	22	680 311 VA22	120%	Including Sutabilizer bushes, (Note 1)
REAR	18	680 311 VB18		For standard Sutabilizer bushes

(Note 1): Some vehicles use stanndard sutabilizer bushes

