

## VACANZA ANTI-SWAY BAR

Car	Model			
Attachment Position	OUTER DIAMETER	PARTS No.	Ratio with Standard	Remarks
<b>TOYOTA</b>				
<b>ESTIMA</b>		<b>TCR##W</b>		
FRONT	29	807 311 VA29		For standard Sutabilizer bushes
<b>ESTIMA</b>		<b>ACR,MCR3 0 W</b>		
FRONT	30	814 311 VA30	159%	Including Sutabilizer bushes,
<b>ESTIMA</b>		<b>ACR,MCR4 0 W</b>		
FRONT	28	813 311 VA28	146%	Including Sutabilizer bushes,
<b>ESTIMA EMINA,LUCIDA</b>		<b>TCR * G</b>		
FRONT	30	810 311 VA30		Including Sutabilizer bushes and Brackets
<b>ALPHARD</b>		<b>ANH10W</b>		
FRONT	30	814 311 VA30	159%	Including Sutabilizer bushes,
<b>Bb</b>		<b>NCP31(2WD)</b>		
FRONT	28	134 311 VA28	140%	Including Sutabilizer bushes,
<b>NOAH,BOXY(2WD)</b>		<b>AZR 6 0 G</b>		
FRONT	28	815 311 VA28	152%	Including Sutabilizer bushes,
<b>NOAH,BOXY(4WD)</b>		<b>AZR 6 5 G</b>		
FRONT	28	816 311 VA28	142%	Including Sutabilizer bushes,
<b>CALDINA</b>		<b>ST215G(NA/4WD)</b>		
FRONT	25	192 311 VA25	137%	Including Sutabilizer bushes,
REAR	19	192 311 VBJ19	154%181%	Two-step adjustment, Including Sutabilizer bushes