

## HYPER RUBBER BUSHING

Car	Model	Description	Necessary pieces	PARTS No.	Remarks
-----	-------	-------------	------------------	-----------	---------

## TOYOTA

Starlet	EP71	F: LOWER ARM BUSHES	1set	102 916 A	Rear side. For early model. ~ 86.11
		F: LOWER ARM BUSHES	1set	104 916 A	Rear side. For later model. 86.12 ~
		F: STABILIZER BUSHES	1set	102 917 A	Body side.
		F: STABILIZER BUSHES	1set	116 918 A	Lower arm side.
	EP82	F: LOWER ARM BUSHES	1set	104 916 A	Front side. Not for round shape type head light.
		F: STABILIZER BUSHES	1set	116 918 A	Lower arm side.
CELICA CARINA	TA10 ~ 40	TRANSMISSION MOUNT	1set	116 912 A	
Corrola Sprinter	TE27 ~ 71	TRANSMISSION MOUNT	1set	116 912 A	For T50 transmission.
	AE86	ENGINE MOUNT	1set	116 910 A	For 4A-G engine.
		TRANSMISSION MOUNT	1set	116 912 A	For T50 transmission.
		TENSION ROD BUSHUES	1set	116 913 A	
		F: LOWER ARM BUSHES	1set	116 914 A	
		F: STABILIZER BUSHES	1set	116 917 A	Body side.
		F: STABILIZER BUSHES	1set	116 918 A	Lower arm side.
		R: CONTOROL ARM BUSHES	4sets	116 919 A	
		R: STABILIZER BUSHES	1set	116 923 A	Body side.
	AE92	F: LOWER ARM BUSHES	1set	120 915 A	Front side.
		F: LOWER ARM BUSHES	1set	120 916 A	Rear side.
		F: STABILIZER BUSHES	1set	116 918 A	For early and GT glade only.
		R: CONTOROL ARM BUSHES	1set	135 921 A	Out side.
		R: CONTOROL ARM BUSHES	1set	135 921 A	Body side.
	AE101	F: LOWER ARM BUSHES	1set	120 915 A	Front side.
		F: LOWER ARM BUSHES	1set	122 916 A	Rear side. Not for 95.5 ~ .
		R: CONTOROL ARM BUSHES	1set	135 921 A	Out side.
		R: CONTOROL ARM BUSHES	1set	135 921 A	Body side.
MR-2	AW11	TENSION ROD BUSHUES	1set	116 913 A	
		F: LOWER ARM BUSHES	1set	135 914 A	
		R: CONTOROL ARM BUSHES	1set	135 921 A	Body side.
		R: CONTOROL ARM BUSHES	1set	116 913 A	Lower arm side.
		R: LOWER ARM BUSHES	1set	135 914 A	
	SW20	ENGINE MOUNT	1set	138 910 A	For turbo charger.
		F: LOWER ARM BUSHES	1set	135 914 A	
		R: CONTOROL ARM BUSHES	1set	135 921 A	Body side.
		R: CONTOROL ARM BUSHES	1set	116 913 A	Lower arm side.
		R: LOWER ARM BUSHES	1set	137 924 A	
		F: TENSION ROD BUSHUES	1set	116 913 A	~ 91.12

## NISSAN

SUNNY	B310	ENGINE MOUNT	1set	213 910 A	For A## engine.
SKYLINE FIRRADY Z	R32 Z32	TENSION ROD BUSHUES	1set	220 913 A	Not for 4WD.
		STEERING COLUMN BUSH	1set	220 922 A	
		R: LOWER ARM BUSHES	1set	220 926 A	Not for BNR32 GT-R.
		R: CONTOROL ARM BUSHES	1set	220 919 A	Not for HICAS.
		R: CONTOROL ARM BUSHES	1set	220 919 AH	For HICAS.
		R: STABILIZER BUSHES	1set	220 923 A	
SILVIA 180SX	S13, RS13	ENGINE MOUNT	1set	223 910 A	For SR20DET engine.
		TENSION ROD BUSHUES	1set	220 913 A	
		F: LOWER ARM BUSHES	1set	220 914 A	
		F: STABILIZER BUSHES	1set	220 918 A	Lower arm side.
		R: LOWER ARM BUSHES	1set	220 926 A	
		R: CONTOROL ARM BUSHES	1set	220 919 A	Not for HICAS.
		R: CONTOROL ARM BUSHES	1set	220 919 AH	For HICAS.
		R: STABILIZER BUSHES	1set	220 923 A	
		STEERING COLUMN BUSH	1set	220 922 A	
SILVIA	S14, S15	ENGINE MOUNT	1set	223 910 A	For SR20DET engine.

TENSION ROD BUSHUES	1set	220 913 A	
F: STABILIZER BUSHES	1set	220 918 A	Lower arm side.
R: CONTROL ARM BUSHES	1set	220 919 A	Not for HICAS.
R: CONTROL ARM BUSHES	1set	220 919 AH	For HICAS.