

LICENCE PLATE OFFSET STAY

Car	Model	Model Year	PARTS No.	Rmarks
TOYOTA				
LEVIN, TORUENO	AE86	83.5 ~ 87.5	116 550 L	
LEVIN	AE92(NA)	87.6 ~ 91.5	120 550 L	Not for later model.
TORUENO	AE92(NA)	87.6 ~ 91.5	121 550 L	Not for later model.
MR-2	AW10/11	84.6 ~ 89.9	135 550 L	
	SW20		137 550 L	
CALDINA			190 550 L	
	AE92(NA)	87.6 ~ 91.5	192 550 L	
SUPRA	AE86	83.5 ~ 87.5	161 550 L	Not for turbo A model.

NISSAN

PULSER	JN15	95.1 ~	275 550 L	It is necessary to make holes.
PREMERA	HP10	90.2 ~ 95.8	256 550 R	Right side.
SILVIA	S13,PS13	86.4 ~ 93.10	220 550 L	
	S13,PS13	86.4 ~ 93.10	220 550 LA	For genue aero bumper only.
	S14(EARY)	93.10 ~ 96.6	222 550 L	
	S14(LATER)	96.7 ~ 98.12	222 550 LN	
180SX	R(P)S13	89.4 ~	220 550 L	Lower side.
AVENIR	W10	90.2 ~	260 550 L	Lower right side
CEFIRO	A31	88.9 ~ 94.7	245 550 R	Lower left side
LAUREL	C33	88.12 ~ 92.12	245 550 L	Lower left side
SKYLINE GT-R	BNR32	89.8 ~ 94.12	231 550 L	
	BCNR33	95.1 ~ 98.12	233 550 L	
	BNR34	99.1 ~	281 550 L	
SKYLINE	HCR32	89.5 ~ 93.8	230 550 L	For GT-S only. Lower left side
	R34	98.6 ~	281 550 L	For GT-S only.
FAIRLADY Z	Z32	89.7 ~	249 550 L	

HONDA

CIVIC	EF3,9	87.9 ~ 91.8	307 550 L	It is necessary to make holes.
	EG6	91.8 ~ 95.8	315 550 L	It is necessary to make holes.
	EK4	95.9 ~	311 550 L	It is necessary to make holes.
	EK9	97.9 ~	317 550 L	It is necessary to make holes.
INTEGRA	DA6	89.4 ~ 93.5	319 550 L	Lower side.
	DC2	93.6 ~	320 550 L	It is necessary to make holes.
	DC2(Type-R)	95.10 ~	321 550 L	It is necessary to make holes.
CRV	RD1	95.10 ~ 98.11	377 550 A	Lower side. For sports grill only.
US ACCORD WAGON	CB9	91.4 ~	335 550 L	It is necessary to make holes.
	CE1(EARY)	94 ~ 95.9	336 550 A	It is necessary to make holes.
	CE1(LATER)		336 550 AN	It is necessary to make holes.
	CF2	96.9 ~ 97.9	336 550 AN	Chassis No.1600000 ~ 1699999
	CF6	97.10 ~	342 550 A	Lower side.
ODYSSEY	RA1,2,6,8	94.10 ~	355 550 A	Lower side.

MAZDA

ROADSTAR	NA6CE	89.9 ~ 93.8	404 550 L/R	Please choose the right side or the left side.
	NA8C	93.8 ~	404 550 L/R	Please choose the right side or the left side.
RX-7	FC3S	85.9 ~ 91.11	420 550 L	
	FD3S	91.12 ~	422 550 L	Lower side.
FORD TELSTAR	GVFWF	91.9 ~	430 550 L	Lower side.
CAPELLA CARGO	GVFW	88.3 ~	430 550 L	

MITSUBISHI

MIRAGE/ASTY	CJ4A	95.10 ~	550 550 L	It is necessary to make holes.
LANCER	CD9A,CE9A	92.10 ~ 96.9	509 550 R	Evo. , It is necessary to make holes.

	CP9A(Evo.)	98.1 ~ 98.12	561 550 A	Upper side.
FTO	DE3A	94.12 ~	540 550 L	
GTO	Z16A	90.10 ~	530 550 R	Lower right side. It is necessary to make holes.

SUBARU

IMPREZA WAGON	GF3	93.10 ~	661 550 L	It is necessary to make holes.
IMPREZA	GC8	92.11 ~ 00.8	660 550 L	Model:A ~ G, It is necessary to make holes.
FORESTAR	SF5	97.2 ~	675 550 A	Lower side.
LEGACY	BF5	89.1 ~ 93.10	657 550 L	
TOURING WAGON	BG5	93.11 ~	658 550 L	
	BH5	98.6 ~	680 550 A	Lower side.

SUZUKI

CAPPUCCINO	EA11R	91.10 ~	606 550 L	Right side.
------------	-------	---------	-----------	-------------