

PILLOW BALL BUSHING

These pillow ball bushing need welding after press in.

Car	Model	Description	Necessary pieces	PARTS No.	Remarks
-----	-------	-------------	------------------	-----------	---------

TOYOTA

Starlet	EP71	F: LOWER ARM BUSHES	1set	102 464 BV	Front side. (Note 1)
		F: LOWER ARM BUSHES	1set	102 464 C	Rear side. Including brackets.
		TWIST BEAM BUSHES	1set	102 464 F	~ 86.11
		TWIST BEAM BUSHES	1set	102 464 FN	86.12 ~
	EP82	F: LOWER ARM BUSHES	1set	102 464 BV	Front side. (Note 1)
		F: LOWER ARM BUSHES	1set	104 464 C	Rear side. Including brackets.
		TWIST BEAM BUSHES	1set	104 464 FV	(Note 1)
Corrola Sprinter	AE86,TE71	F: LOWER ARM BUSHES	1set	116 464 A	
		R: CONTOROL ARM BUSHES	4sets	116 464 D	
	AE92	F: LOWER ARM BUSHES	1set	120 464 BV	Front side. (Note 1)
		F: LOWER ARM BUSHES	1set	120 464 CV	Rear side. Including brackets. (Note 1)
	AE101	F: LOWER ARM BUSHES	1set	120 464 BV	Front side. (Note 1)
		F: LOWER ARM BUSHES	1set	122 464 CV	Rear side. (Note 1)
		R: STRUT ROD BUSHES	2sets	137 464 EV	(Note 1)
MR-2	AW11	F: LOWER ARM BUSHES	1set	137 464 AV	(Note 1)
		R: LOWER ARM BUSHES	1set	137 464 AV	(Note 1)
		R: STRUT ROD BUSHES	1set	137 464 EV	Body side. (Note 1)
	SW20	F: LOWER ARM BUSHES	1set	137 464 AV	(Note 1)
		R: LOWER ARM BUSHES	1set	137 464 HV	(Note 1)
		F: TENSION BUSHES	1set	137 464 G	For later model. 92.1 ~
		R: TENSION BUSHES	1set	137 464 EV	Body side. (Note 1)
MR-S	ZZW30	F: LOWER ARM BUSHES	1set	157 464 BV	Front side. (Note 1)
		F: LOWER ARM BUSHES	1set	157 464 CV	Rear side. (Note 1)
		R: STRUT ROD BUSHES	1set	157 464 EV	Body side. (Note 1)
		R: LOWER ARM BUSHES No.1	1set	157 464 HV	(Note 1)
		R: LOWER ARM BUSHES No.2	1set	157 464 HV	(Note 1)
		R: KNUCLE BUSHES	1set	157 464 NV	(Note 1)
ALTEZZA	SXE10	F: LOWER ARM BUSHES	1set	195 464 CV	Rear side. (Note 1)

(Note 1) Including rubber boots.