

AERO HOOD & TRUNK LID (FRP)

Car	Model	Model Year	Description	PARTS No.	Rmarks
-----	-------	------------	-------------	-----------	--------

TOYOTA

STARLET	EP82 (TURBO)	89.11 ~ 95.11	BONNET	105 810 A	Not air scoop type.
			REAR GATE	105 811 A	
LEVIN	AE86	83.5 ~ 87.5	BONNET	116 810 A	
			TRUNK	116 812 A	
			REAR GATE	117 811 A	
	AE92(NA)	87.6 ~ 91.5	BONNET	120 810 A	
TORUENO	AE86	83.5 ~ 87.5	BONNET	118 810 A	
			TRUNK	116 812 A	
			REAR GATE	117 811 A	
CELICA GT4	ST165	87 ~ 89.7	BONNET	151 810 A	
	ST185	89.8 ~ 94.2	BONNET	152 810 A	
MR-2	AW10/11	84.6 ~ 89.9	BONNET	135 810 A	
			TRUNK	135 812 A	
			ENGINE HOOD	135 811 A	For NA

NISSAN

SILVIA	S13,PS13	86.4 ~ 93.10	BONNET	220 810 A	
	S14	93.10 ~ 96.11	BONNET	222 810 A	For early model.
180SX	R(P)S13	89.4 ~ 98.12	BONNET	221 810 A	

HONDA

CITY	GA2	88.9 ~	BONNET	302 810 A	
			REAR GATE	302 811 A	
CIVIC	EG6	91.9 ~ 95.8	BONNET	315 810 A	
			TRUNK	315 812 A	This bonnet can use standard striker.

SUBARU

IMPREZA	GDA/GDB	00.9 ~ 02.10	GT TYPE BONNET	667 810 GT	
			TRUNK	667 812 A	
	GC8 Model:D,E,F,G	01.1 ~	AERO BONNET	660 810 D	Aero type, This bonnet can use standard striker.
			AERO BONNET	660 810 DC	Cabon, This bonnet can use standard striker.

MITSUBISHI

MIRAGE	C53,73,83	91.10 ~ 95.9	BONNET	511 810 A	
	CA4A	91.10 ~ 95.9	BONNET	516 810 A	
LANCER	CD5A	91.10 ~	BONNET	508 810 A	
	CD9A,CE9A Evo. , ,	92.10 ~ 96.9	BONNET	509 810 A	Non duct type.
			TRUNK	509 812 A	
	CN9A Evo.	96.10 ~ 98.12	BONNET	560 810 A	
			TRUNK	560 812 A	
	CP9A Evo. ,	99.1 ~ 01.4	BONNET	561 810 A	
			TRUNK	560 812 A	
	CT9A Evo.	01.4 ~	AERO BONNET	564 810 D	Aero type, This bonnet can use standard striker.
			TRUNK	564 812 A	
GALANT	E38A,39A	87.8 ~ 92.4	BONNET	517 810 A	Non duct type.