

## STURUT BAR

<b>CUSCO STRUT BAR</b> (Ti) TITANIUMU SHAFT (CB) 40 CARBON FIBER SHAFT (ALC 40 ) 40ALUMINUM & CARBON FIBER SHAFT (40 ) 40ALUMINUMU PIPE SHAFT (40D) 40 D SECTIOND ALUMINUMU PIPE SHAFT	(ALCOS) OVAL SECTION ALUMINUMU & CARBON FIBER SHAFT (OS) ALUMINUMU OVAL SHFT (AS) ALUMINUMU SHAFT (ST) STEAL SHAFT (OS-T) REAR TRIANGLE TYPE SUPPLEMENTARY BRACE
-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Vacanza STRUT BAR</b> (VAC) ALUMINUMU OVAL SHAFT
--------------------------------------------------------

<b>CUSCO LOWER ARM BAR</b> ( ) LOWER ARM BAR VERSION ( ) LOWER ARM BAR VERSION	<b>Vacanza LOWER ARM BAR</b> (VAC ) LOWER ARM BAR VERSION (VAC ) LOWER ARM BAR VERSION
--------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------

Description	FRONT			REAR		
	Type	PARTS No.	Remarks	Type	PARTS No.	Remarks

## MITSUBISHI

Car	Model	Model Year			
<b>PAJERO MINI</b>	<b>H56A</b>	94.12 ~			
STRUT BAR	OS	820 540A	Not for NA,H58A.		
	AS	820 510A	Not for NA.		
LOWER ARM BAR		820 475A			
STRUT BAR	VAC	820 540V	Not for NA,H58A.		
LOWER ARM BAR	VAC	820 475V			
<b>MINICA</b>	<b>H21 ~ H27</b>	89.1 ~ 93.9			
STRUT BAR	ST	500 510A	Not for Carburetor model.		
	<b>H36</b>	93.10 ~			
STRUT BAR	ST	503 510A			
<b>MIRAGE</b>	<b>C53,C73,C83</b>	87.9 ~ 91.9			
STRUT BAR	AS	511 510A		AS	511 511A
	<b>CA3A,CA4A,CC4A</b>	91.10 ~			
STRUT BAR	OS	514 540A		OS	508 541A
	AS	508 510A		AS	508 511A
				CB	508 551A
				40	508 526A
					It is necessary to process rear trim.
<b>MIRAGE,ASTI</b>	<b>CJ4A,CK4A,CJ2A</b>	95.10 ~			
STRUT BAR	OS	550 540A		OS	508 541A
	AS	550 510A		AS	508 511A
				CB	508 551A
				40	508 526A
					It is necessary to make holes.
LOWER ARM BAR		420 475A	For CJ4A,CJ2A. Not for AT.		540 476A
		540 477A	For CJ4A,CJ3A. Not for AT.		
					For CJ4A
<b>RIBERO</b>	<b>CD5W,CB5W</b>	92.5 ~			
STRUT BAR	OS	508 540A			
	AS	508 510A			
<b>RVR</b>	<b>N23WG(2000cc)</b>	92.10 ~			
STRUT BAR	OS	580 540A		OS	580 541A
	AS	580 510A	Not for I/C model.	AS	580 511A
STRUT BAR	VAC	580 540V		VAC	580 541V
<b>FTO</b>	<b>DE3A</b>	94.10 ~			
STRUT BAR	OS	540 540A		OS	508 541A
	ST	540 510A		AS	508 511A
LOWER ARM BAR		540 475A	Not for AT.		540 476A
		540 477A	Not for AT.		
	<b>DE2A</b>	94.10 ~			
STRUT BAR				OS	508 541A
				AS	508 511A
LOWER ARM BAR		540 475A	Not for AT.		
					For early model.
<b>STARION</b>	<b>A183A,A184A,A187A</b>	82.4 ~ 90.5			
STRUT BAR	ST	405 510A			
<b>LANCER</b>	<b>A175A</b>	81.10 ~ 87.10			
STRUT BAR	ST	506 510A			
	<b>C63,C73</b>	88.5 ~ 91.9			
STRUT BAR	AS	511 510A		AS	511 511A
	<b>CD5A,CB4A</b>	91.11 ~			
STRUT BAR	OS	550 540A		OS	508 541A
				OS-T	508 544A
					It is necessary to use with strut brace.

	AS	508 510A		AS	508 511A	It is necessary to process rear trim.
LOWER ARM BAR		514 475A	For CD5A			
		<b>CM5A,CK4A</b>	95.11 ~			
STRUT BAR	OS	550 540A		OS	508 541A	It is necessary to process rear trim.
	AS	550 510A		AS	508 511A	It is necessary to process rear trim.
	CB	560 555A				
<b>LANCER CEDIA WAGON</b>		<b>CS5W(2WD)</b>	00.08 ~			
STRUT BAR	OS	571 540A				
LOWER ARM BAR		571 475A				
		571 477A				
STRUT BAR	VAC	571 540V				
LOWER ARM BAR	VAC	571 475V				
	VAC	571 477V				
<b>LANCER EVORUTION</b>		<b>CE9A,CD9A</b>	92.10 ~ 96.9			
STRUT BAR	OS	508 540A		OS	508 541A	It is necessary to process rear trim.
				OS-T	508 544A	It is necessary to use with strut brace.
	AS	508 510A		AS	508 511A	It is necessary to process rear trim.
	CB	508 555A		CB	508 551A	It is necessary to process rear trim.
	40	508 525A		40	508 526A	It is necessary to process rear trim.
LOWER ARM BAR		514 475A				
		510 477A	For CE9A			
		<b>CN9A,CP9A</b>	96.10 ~ 01.1			
STRUT BAR	OS	550 540A		OS	560 541A	It is necessary to process rear trim.
	OS	560 540AT	TRIANGLE TYPE.	OS-T	508 544A	It is necessary to use with strut brace.
	AS	550 510A		AS	560 511A	It is necessary to process rear trim.
	CB	560 555A		CB	560 551A	It is necessary to process rear trim.
	40	560 525A		40	560 526A	It is necessary to process rear trim.
	Ti	560 547AT	TRIANGLE TYPE.about 1000g.			
LOWER ARM BAR		560 475A	For CN9A.			
		560 477A	For CN9A.			
		561 475A	For CP9A.			
		561 477A	For CP9A.			
REAR TRUNK BAR		560 490A	It is necessary to process trim.			
		<b>CT9A Evo7(in GTA),E</b>	01.1 ~			
STRUT BAR	OS	565 540A		OS	560 541A	It is necessary to process rear trim.
	OS	565 540AT	TRIANGLE TYPE.	OS-T	508 544A	It is necessary to use with strut brace.
	AS	565 510A		AS	560 511A	It is necessary to process rear trim.
	CB	565 555A		CB	560 551A	It is necessary to process rear trim.
	40	565 525A		40	560 526A	It is necessary to process rear trim.
	Ti	564 547AT	TRIANGLE TYPE.about 1000g.			
LOWER ARM BAR		564 475A				
		564 477A				
REAR TRUNK BAR		560 490A	It is necessary to process trim.			
<b>GALANT</b>		<b>A164A</b>	80 ~ 83			
STRUT BAR	ST	522 510A				
		<b>E37,38,39</b>	87.8 ~ 92.4			
STRUT BAR	OS	517 540A	Not for wearing auto cruise model. Not for ABS.	OS	517 541A	It is necessary to process rear trim.
	AS	517 510A		AS	517 511A	It is necessary to use with strut brace.
		<b>E52,53,54</b>	92.5 ~ 96.7			
STRUT BAR	OS	520 540A	Not for 1800&2000cc model. Not for Carburetor model.			
	AS	520 510A				
<b>LEGNUM</b>		<b>EC3W,EA1W,EA3W,EC</b>	98.8 ~			
STRUT BAR	OS	534 540A		OS	535 541A	Not for EA1A.
				AS	535 511a	It is necessary to process rear trim.
LOWER ARM BAR		534 475A				
STRUT BAR	VAC	534 540V		VAC	535 541V	Not for EA1A.
LOWER ARM BAR	VAC	534 475V				
		<b>EC5W,EA1W,EC1W,EA</b>	96.6 ~ 98.8			
STRUT BAR	OS	535 540A		OS	508 541A	It is necessary to process rear trim.
	AS	535 510A		AS	508 511A	It is necessary to process rear trim.
LOWER ARM BAR		535 475A				
		535 477A				
STRUT BAR	VAC	535 540V		VAC	535 541V	It is necessary to process rear trim.
LOWER ARM BAR	VAC	535 475V				
	VAC	535 477V				
<b>GTO</b>		<b>Z16A</b>	90.10 ~			
STRUT BAR				OS	530 541A	It is necessary to process rear trim.

				AS	530 511A	It is necessary to process rear trim.
<b>DIAMANTE</b>	<b>F13/15/17,F25A</b>	90.5 ~ 94.2				
STRUT BAR	AS	526 510A		AS	526 511A	It is necessary to process rear trim.