

**URETHANE BUSHING**

| Car | Model | Description | Necessary<br>pieces | PARTS No. | Remarks |
|-----|-------|-------------|---------------------|-----------|---------|
|-----|-------|-------------|---------------------|-----------|---------|

**TOYOTA**

|                     |      |                        |       |           |                       |
|---------------------|------|------------------------|-------|-----------|-----------------------|
| Starlet             | EP71 | F: STABILIZER BUSHES   | 1set  | 102 917 A | Lower arm side.       |
|                     | EP82 | F: STABILIZER BUSHES   | 1set  | 116 918 A | Lower arm side.       |
| Corrola<br>Sprinter | TE71 | R: CONTOROL ARM BUSHES | 2sets | 116 919 A | For T50 transmission. |
|                     |      | TENSION ROD BUSHUES    | 1set  | 116 913 A |                       |
|                     | AE86 | TENSION ROD BUSHUES    | 1set  | 116 910 A | For 4A-G engine.      |
|                     |      | F: STABILIZER BUSHES   | 1set  | 116 912 A | For T50 transmission. |
|                     |      | R: STABILIZER BUSHES   | 1set  | 116 913 A |                       |
|                     |      | R: CONTOROL ARM BUSHES | 2sets | 116 914 A |                       |
|                     |      | REAR SHOCKS BUSHES     | 1set  | 116 917 A | Body side.            |
| MR-2                | AW11 | TENSION ROD BUSHUES    | 1set  | 116 913 A |                       |
|                     |      | R: STRUT ROD BUSHES    | 1set  | 135 921 A | Body side.            |

**HONDA**

|               |               |                       |      |           |                |
|---------------|---------------|-----------------------|------|-----------|----------------|
| CIVIC<br>CR-X | EF2,3,6,7,8,9 | SHOCK-ABSORBER BOSHES | 1set | 220 913 A | Not for 4WD.   |
|               | EG2,4,6,8,9   |                       |      |           |                |
|               | EK4           |                       |      |           |                |
| INTEGRA       | DA6           | SHOCK-ABSORBER BOSHES | 1set | 220 919 A | Not for HICAS. |