

TOYOTA

Corrola II, TERCEL, CORSA

Starlet

MR-SMR-2

Corrola, Sprinter

Corrola FX

SERA

CYNOS

CORONA

CELLICA.CARINA

[illegible]

ST162	85~87	Adjustable	151 410 A	A	01						
ST18#	89.8~93.10	Adjustable	151 410 A	A	01						
ST202	93.10~99.9	Adjustable	153 410 A	A	01						
ZZT231	99.10~	Adjustable	157 410 A	A	01 / 68						
CELICA GT4											
ST165	87~89.7	Adjustable	151 410 A	A	01		Non adjustable	125 421 A		01	For STD type springs.
							Adjustable	125 420 A	A	01	(Note 1)
ST185	89.8~93.9	Adjustable	151 410 A	A	01		Non adjustable	152 421 A	B	01	(Note 1)
ST205	93.10~	Adjustable	153 410 A	A	01 / 68		Non adjustable	153 421 A	A	03	For STD type springs.
ALTEZZA											
SXE10	98.10~	Non adjust	195 411 A	I	67	For STD type & ID70 springs.					
		Non adjust	195 411 A65	I	67	For ID65 springs.					
		Non adjust	195 411 A60	I	67	For ID60 springs.					
CELICA XX											
GA,MA61	80~86.1	Adjustable	180 410 A	B	04						
SUPRA											
GA70, MA70	86.2~93.5	Non adjust	183 411 A	I	05		Non adjustable	183 421 A	H	06	For STD type springs.
		Non adjust	183 411 A70	I	05	For ID70,75 springs.	Non adjustable	183 421 A70	H	06	For ID70,75 springs.
		Non adjust	183 411 A60	I	05	For ID60 springs.	Non adjustable	183 421 A60	H	06	For ID60 springs.
		Non adjust	183 411 A65	I	05	For ID65 springs.	Non adjustable	183 421 A65	H	06	For ID65 springs.
JZA70	90.8~93.5	Non adjust	183 411 A	I	05		Non adjustable	183 421 A	H	06	For STD type springs.
		Non adjust	183 411 A70	I	05	For ID70,75 springs.	Non adjustable	183 421 A70	H	06	For ID70,75 springs.
		Non adjust	183 411 A60	I	05	For ID60 springs.	Non adjustable	183 421 A60	H	06	For ID60 springs.
		Non adjust	183 411 A65	I	05	For ID65 springs.	Non adjustable	183 421 A65	H	06	For ID65 springs.
JZA80	93.6~	Non adjust	183 411 A	I	05		Non adjustable	183 421 A	H	06	For STD type springs.
		Non adjust	183 411 A70	I	05	For ID70,75 springs.	Non adjustable	183 421 A70	H	06	For ID70,75 springs.
		Non adjust	183 411 A60	I	05	For ID60 springs.	Non adjustable	183 421 A60	H	06	For ID60 springs.
		Non adjust	183 411 A65	I	05	For ID65 springs.	Non adjustable	183 421 A65	H	06	For ID65 springs.
MARK II,CRESTA,CHASER											
GX61	80.3~82.7	Adjustable	170 410 A	B	04	For early models.					
GX61	82.8~84.7	Adjustable	171 410 A	B	04	For later models.					
GX71,GX70G	84.8~88.7	Adjustable	180 410 A	B	04						
GX81,JZX81	88.8~92.10	Adjustable	173 410 A	A	01	(Note 1)	Non adjustable	173 421 A	I	08	For STD type springs.
		Non adjust	173 411 A	A	01	For TEMS					
JZX90	92.10~96.9	Non adjust	174 411 A	I	27	For STD type & ID70 springs.					
		Non adjust	174 411 A60	I	27	For ID60 springs.					
		Non adjust	174 411 A65	I	27	For ID65 springs.					
JZX100,GX100	96.10~	Non adjust	174 411 A	I	27	For STD type & ID70 springs.	Non adjustable	175 421 A	I	27	For STD type springs.
		Non adjust	174 411 A60	I	27	For ID60 springs.	Non adjustable	175 421 A70	I	27	For ID70 springs.
		Non adjust	174 411 A65	I	27	For ID65 springs.	Non adjustable	175 421 A60	I	27	For ID60 springs.
							Non adjustable	175 421 A65	I	27	For ID65 springs.
SOARER											
GZ10	81.2~85.12	Adjustable	180 410 A	B	04						
MZ10, MZ11,12	81.2~85.1	Adjustable	180 410 A	B	04						
GZ20, MZ20,21	86.1~91.6	Non adjust	183 411 A	I	05	For STD type springs.	Non adjustable	183 421 A	H	06	For STD type springs.
		Non adjust	183 411 A70	I	05	For ID70,75 springs.	Non adjustable	183 421 A70	H	06	For ID70,75 springs.
		Non adjust	183 411 A60	I	05	For ID60 springs.	Non adjustable	183 421 A60	H	06	For ID60 springs.
		Non adjust	183 411 A65	I	05	For ID65 springs.	Non adjustable	183 421 A65	H	06	For ID65 springs.
JZZ30	91.7~	Non adjust	183 411 A	I	05	For STD type springs.	Non adjustable	183 421 A	H	06	For STD type springs.
		Non adjust	183 411 A70	I	05	For ID70,75 springs.	Non adjustable	183 421 A70	H	06	For ID70,75 springs.
		Non adjust	183 411 A60	I	05	For ID60 springs.	Non adjustable	183 421 A60	H	06	For ID60 springs.
		Non adjust	183 411 A65	I	05	For ID65 springs.	Non adjustable	183 421 A65	H	06	For ID65 springs.
ARISTO											
JZS161	97.8~	Non adjust	187 411 A	H6	62	For STD type & ID70 springs.					
		Non adjust	187 411 A65	H6	62	For ID65 springs.					
		Non adjust	187 411 A60	H6	62	For ID60 springs.					
		Non adjust	187 411 A70	H6	62	For ID70,75 springs.					
Fan Cargo											
NCP21	99.8~	Adjustable	114 410 A	H	61						
bB											
NCP31,35	00.1~	Adjustable	114 410 A	H	61						
LAUM											
EXZ10	97.5~	Adjustable	104 410 A	A	01		Non adjustable	106 421 A70	M1	07	For STD type & ID75 springs.
							Non adjustable	106 421 A60	M1	07	For ID60 springs.
							Non adjustable	106 421 A65	M1	07	For ID65 springs.
Corrola Wagon											
AE100G/101C	91.9~	Adjustable	120 410 A	A	01						
RAV4											
SXA11	94.5~	Adjustable	800 410 A	B	09						
CALDINA											
ST195,190	92.11~95.12	Adjustable	190 410 A	B	09		Non adjustable	190 421 A	B	03	For STD type springs.(Note 3)
ST195,190	96.1~97.9	Adjustable	192 410 A	B	09		Non adjustable	190 421 A60	B	03	For ID60 springs. (Note 3)
							Non adjustable	190 421 A65	B	03	For ID65 springs. (Note 3)
ST215 TURBO	98.1~	Adjustable	192 410 A	B	09		Non adjustable	190 421 A70	B	03	For ID70,75 springs. (Note 3)
Ipsum											
SXM10G,15G	86.5~	Adjustable	803 410 A	A	55						

(Note 1) For straight type springs. Use with optional spring upper seats necessary.

(Note 2) Please check the screw pitch of a shock absorber.

(Note 3) For ST190,195,215